
# 3/4 Lab


- . OpenCV introduction
- 2. Python 3 & opency installation
- 3. Lab01



- o core. The Core Functionality
- o imgproc. Image Processing
- · imgcodecs. Image file reading and writing
- o videoio. Media I/O
- highqui. High-level GUI and Media I/O
- video. Video Analysis
- calib3d. Camera Calibration and 3D Reconstruction
- features2d, 2D Features Framework
- objdetect. Object Detection
- o ml. Machine Learning
- flann. Clustering and Search in Multi-Dimensional Spaces
- photo. Computational Photography
- stitching. Images stitching
- cuda. CUDA-accelerated Computer Vision
- cudaarithm. CUDA-accelerated Operations on Matrices cudabgsegm. CUDA-accelerated Background Segmentation
- cudacodec. CUDA-accelerated Video Encoding/Decoding cudafeatures2d. CUDA-accelerated Feature Detection and Description
- cudafilters. CUDA-accelerated Image Filtering
- cudaimgproc. CUDA-accelerated Image Processing
- cudaoptflow. CUDA-accelerated Optical Flow cudastereo, CUDA-accelerated Stereo Correspondence
- cudawarping. CUDA-accelerated Image Warping
- o shape. Shape Distance and Matching
- o superres. Super Resolution
- videostab, Video Stabilization
- o viz. 3D Visualizer
- bioinspired. Biologically inspired vision models and derivated tools
- cvv. GUI for Interactive Visual Debugging of Computer Vision Programs
- datasets. Framework for working with different datasets o face. Face Recognition
- Binary descriptors for lines extracted from an image
- o optflow. Optical Flow Algorithms
- o reg. Image Registration
- o rgbd. RGB-Depth Processing
- Saliency API
- · surface\_matching. Surface Matching


#### feature detection





pattern recognition

# Mat



rows: 長


cols: 寬


type: 像素型態


channels: 通道數

normal:

#### image:







#### Mat value access

	Column 0	Column 1	Column	Column m
Row 0	0,0	0,1		0, m
Row 1	1,0	1,1		1, m
Row	,0	,1		, m
Row n	n,0	n,1	n,	n, m

#### 3-channel: B, G, R

	Column 0		Column 1		Column		Column m					
Row 0	0,0	0,0	0,0	0,1	0,1	0,1				0, m	0, m	0, m
Row 1	1,0	1,0	1.0	1,1	1,1	1,1				1, m	1, m	1, m
Row	,0	,0	,0	,1	,1	,1				, m	, m	, m
Row n	n,0	n,0	n,0	n,1	n,1	n,1	n,	n,	n,	n, m	n, m	n, m

```
import numpy as np
     import cv2
     #read
     image = cv2.imread("image.jpg")
     #show
     cv2.imshow("My Image", image)
     #按下按鍵關閉顯示視窗
     cv2.waitKey(0)
10
11
     cv2.destroyAllWindows()
```

cv2.imwrite("output.jpg", image)

**12** 13

14

#save

### 標頭引入

```
import numpy as np
import cv2
```

#### 讀寫圖片

```
讀取:
```

```
img = cv2.imread('image.jpg')
```

#### 儲存:

```
cv2.imwrite('output.jpg', img)
```

### 顯示圖片

```
秀出影像:
# 顯示圖片
cv2.imshow('My Image', img)

等待按鍵輸入:
# 按下任意鍵則關閉所有視窗
cv2.waitKey(0)
cv2.destroyAllWindows()
```

## 開一個指定大小的黑圖 複製圖片

```
blank_image = np.zeros((height,width,3), np.uint8)
```

```
newImage = myImage.copy()
```


## 操作像素

image[row, col, channel]

# Windows 10 python 3 & opency

#### 1. 下載python

#### 到<u>官網</u>點選Downloads



#### 1. 下載python

選擇python 3

## **Python Releases for Windows**

- Latest Python 3 Release Python 3.9.2
- Latest Python 2 Release Python 2.7.18

#### 2. 安裝軟體

- 點選並安裝
- 加入環境變數





#### 3. 安裝opencv

- pip install opency-python
- Test:

```
import cv2
img = cv2.imread('kobe.jpg')

cv2.imshow('My Image', img)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

#### 4. 安裝numpy

pip install numpy

```
Collecting numpy

Downloading numpy-1.22.2-cp38-cp38-win_amd64.whl (14.7 MB)

I 14.7 MB 6.4 MB/s

Installing collected packages: numpy
Successfully installed numpy-1.22.2
```

# Lab 01

2. Interpolation (bilinear, nearest neighbor)

1. 圖片灰階與顏色濾鏡

#### 1. 灰階與藍色濾鏡(30%)


- 將原始圖片中的藍點予以保留,並把其餘的點改為灰階。
- Hint: B > 100 and B \* 0.6 > G and B \* 0.6 > R





### 2. Interpolation - 最近相鄰內插法 (30%)

- 根據輸出影像的像素位置,找到輸入影像中最鄰近的點,即當作輸出影像的像素強度。
- 以下圖為例



2. Interpolation - 最近相鄰內插法 (30%)


● 將照片放大3倍





#### 3. Interpolation - 雙線性內插法 (40%)

● 根據輸出影像的像素位置, 找到輸入影像中最鄰近的四個點,再利用雙線性內插法求出輸出影像的像素強度。



## 3. Interpolation - 雙線性內插法 (40%)

- 以參數方式輸入影像以及倍率
- 學會使用 OpenCV API (10%)自行實作雙線性內插法 (40%)
- 下圖為輸入影像 右圖為 倍率=3之結果



